

NEW SITA SurfaSpector

Fast evaluation of surface wettability in manufacturing processes by measuring the contact angle




SITA SurfaSpector

The SITA SurfaSpector is a new hand-held measuring device for testing the wettability of metal, glass and plastic surfaces, e.g. after surface treatment or cleaning. The device combines an objective measurement with simple handling and enables a fast evaluation of the surface.

- Automated measuring procedure including drop placement, drop detection and direct determination of the contact angle
- Handy sensor head for measuring at various parts geometries
- Simple operation via touchscreen
- Mobile use without PC directly at the plant or in the process
- Limit value monitoring in measuring profiles usable for various applications
- Optional PC software SITA-SurfaceLog for advanced measurement data visualization and export

Measuring principle



A drop of water is precisely placed at the surface by an automatic dosing unit. The drop is illuminated from the side. A shadow of the drop is projected onto an inclined measuring surface. The projection is recorded from above by a high resolution camera and the picture is corrected for perspective. The drop shape is determined and the contact angle calculated. The lower the contact angle, the higher the wettability.

Technical Data

Contact angle

Range Resolution Liquid 5°...175° 0.1° pure water, refillable, 5 ml for 5,000 measurements

Method

Operation

Main unit

Sensor

5″ TFT-display 800 x 480 pixel, capacitive touch, intuitive grafical user interface measurement start button, LED for optical feedback

Power supply / interfaces

Li-lon battery 2x 6,400 mAh, min. measurement time 6 hours Power plug 12 V, 2.5 A (max. 17 V, 3 A)

Interfaces and memory

USB Memory USB-C (data transfer, USB-C power delivery) 10 GByte

Dimensions and weight

HxWxD / Weight

Main unit: 80 x 210 x 130 mm / 1,100 g Sensor: 117 x 50 x 82 mm /330 g

Accessories

Calibration standard, stand

Applications

- Quality assurance after parts cleaning
- Wettability inspection
- Testing of surface activation, e.g. after a plasma treatment and many more applications in surface analysis





T. +34 943 82 00 82 info@neurtek.com **www.neurtek.com**

Contact SITA Messtechnik GmbH Gostritzer Straße 63 01217 Dresden Germany Tel. +49 (0)351 871 8041 Fax +49 (0)351 871 8464 www.sita-process.com info@sita-process.com